

# Avionics Loaner List

---

The loaner units available are listed below, if you do not see your part please reach out to us as we are adding new inventory daily.

| Part Description             | Part Number  |
|------------------------------|--------------|
| ADF INDICATOR                | 066-3063-00  |
| ADF INDICATOR                | 066-3063-01  |
| AIRSPEED INDICATOR           | 802513       |
| AIRSPEED INDICATOR           | 101-380068-7 |
| AIRSPEED INDICATOR           | 1429-029     |
| AIRSPEED INDICATOR           | 201530-11373 |
| ALTIMETER                    | 101735-11807 |
| ALTIMETER                    | 31400-017    |
| ALTIMETER                    | 5934M-1      |
| ALTIMETER                    | B0063-81108  |
| ALTIMETER 20K                | 5934P-3A.83  |
| ALTIMETER 35K                | 5934PA-3A.86 |
| ALTIMETER ALERT              | 4018285-904  |
| ALTIMETER PRE-SELECT         | 7004577-903  |
| ALTIMETER, BAROMETRIC        | 4016341-903  |
| ALTIMETER, PRESSURE          | 101450-11722 |
| ALTITUDE, BAROMETRIC         | 4016341-905  |
| AMP METER                    | 10-60757-27  |
| ARTIFICIAL HORIZON INDICATOR | 23-501-06-16 |
| ATTITUDE DIRECTOR            | 2591411-444  |
| ATTITUDE DIRECTOR            | 4020550-901  |
| ATTITUDE DIRECTOR            | 622-4570-001 |
| ATTITUDE DIRECTOR            | 7001182-909  |
| ATTITUDE DIRECTOR            | 7001182-913  |
| ATTITUDE GYRO                | 23-501-017   |
| ATTITUDE GYRO                | 23-501-018   |
| ATTITUDE GYRO                | 23-501-06-3  |
| ATTITUDE GYRO                | 504-0017-907 |

| Part Description                     | Part Number    |
|--------------------------------------|----------------|
| ATTITUDE GYRO                        | 504-0035-921   |
| ATTITUDE GYRO                        | 700-3CF        |
| ATTITUDE INDICATOR                   | 504-0017-901   |
| AUX POWER SUPPLY                     | 501-1228-03    |
| BATTERY TEMP MONITOR                 | 522487-1       |
| CABIN PRESSURIZATION, 28 VDC         | 10388N02C00    |
| CDI NAV/GPS/3C                       | MD200-306 3    |
| CLOCK DIGITAL                        | 73910193-001   |
| COURSE INDICATOR                     | 2592920-445    |
| COURSE INDICATOR                     | 522-2638-003   |
| COURSE INDICATOR                     | 522-2782-004   |
| COURSE INDICATOR                     | 522-3073-000   |
| COURSE INDICATOR                     | 522-3342-005   |
| COURSE INDICATOR                     | 522-3875-001   |
| COURSE INDICATOR                     | 787-6385-005   |
| DAVTRON DIGITAL CHRONOMETER          | 10-24535-14    |
| DC POWER MONITOR                     | 522778         |
| DC VOLT METER                        | 114-380032-1   |
| DIRECTIONAL GYRO                     | 060-0001-00    |
| DIRECTIONAL GYRO                     | 1U262-042-2    |
| DIRECTIONAL GYRO                     | 2587193-33     |
| DIRECTIONAL GYRO                     | 2587193-43     |
| DIRECTIONAL GYRO                     | 2588302-3      |
| DIRECTIONAL GYRO                     | 4020577-3      |
| DIRECTIONAL GYRO                     | 622-6136-001   |
| DIRECTIONAL GYRO, 332E-4             | 522-3241-000   |
| DIRECTIONAL GYRO, 4000B-30           | 1U262-001-39   |
| DIRECTIONAL GYRO, DGS-65             | 622-6136-002   |
| DIRECTIONAL GYRO, KG-102A            | 060-0015-00    |
| DUAL HYDRAULIC PRESSURE INDICATOR    | 5427-115-80-10 |
| ENCODING ALTIMETER                   | 066-03064-0005 |
| ENCODING ALTIMETER                   | 101627-01344   |
| FLIGHT COMMAND INDICATOR             | 060-0017-00    |
| FLIGHT DIRECTOR / ATTITUDE INDICATOR | 522-3206-006   |
| FLIGHT DIRECTOR / ATTITUDE INDICATOR | 522-3487-002   |
| FLIGHT DIRECTOR INDICATOR            | 4000369-8505   |

| Part Description               | Part Number     |
|--------------------------------|-----------------|
| FLIGHT DIRECTOR INDICATOR      | 4002531-903     |
| FLIGHT DIRECTOR INDICATOR      | 522-3206-007    |
| FLIGHT DIRECTOR INDICATOR      | 522-3206-008    |
| FLIGHT DIRECTOR INDICATOR      | 522-3487-001    |
| FLIGHT DIRECTOR INDICATOR      | 792-6355-001    |
| FLIGHT DISPLAY INDICATOR       | 622-0757-001    |
| FUEL FLOW INDICATOR            | 10171N04F03     |
| FUEL FLOW INDICATOR            | 25514B25A3A3    |
| FUEL FLOW INDICATOR            | 9-464-02        |
| FUEL QUANTITY INDICATOR        | 10010-0000-02   |
| FUEL QUANTITY INDICATOR        | 10013-0000-02   |
| FUEL QUANTITY INDICATOR        | 10048-0000-01   |
| FUEL QUANTITY INDICATOR        | 206-075-189-001 |
| FUEL QUANTITY INDICATOR        | 393004-060      |
| FUEL TEMP INDICATOR            | 5427-218-80-10  |
| GYRO, RATE                     | GG205A4         |
| GYRO, SLAVED                   | 4000869-3201    |
| GYRO, VERTICAL                 | 4001808-901     |
| GYRO, VERTICAL                 | 622-4565-002    |
| HIGH PRESSURE INDICATOR        | 10170N01R00     |
| HORIZON GYRO                   | 4020501-431     |
| HORIZON GYRO                   | 4020531-574     |
| HORIZON GYRO                   | 4021541-671     |
| HORIZON GYRO                   | 501-1105-04     |
| HORIZON GYRO                   | 504-0010-904    |
| HORIZON GYRO                   | H341ADM2        |
| HORIZON INDICATOR              | 102-0071-03     |
| HORIZON INDICATOR              | 500ED           |
| HORIZON INDICATOR, STANDBY     | H301BDM1        |
| HORIZON REFERENCE              | 300-3BCF        |
| HORIZON REFERENCE              | 500E,K          |
| HORIZONTAL SITUATION INDICATOR | 066-3024-47     |
| HORIZONTAL SITUATION INDICATOR | 2592920-901     |
| HORIZONTAL SITUATION INDICATOR | 4000172-8503    |
| HORIZONTAL SITUATION INDICATOR | 4000458-6303    |
| HORIZONTAL SITUATION INDICATOR | 4020553-901     |

| Part Description               | Part Number    |
|--------------------------------|----------------|
| HORIZONTAL SITUATION INDICATOR | 4027170-904    |
| HORIZONTAL SITUATION INDICATOR | 522-2638-007   |
| HORIZONTAL SITUATION INDICATOR | 622-4913-001   |
| HORIZONTAL SITUATION INDICATOR | 7000469-905    |
| HORIZONTAL SITUATION INDICATOR | 7001179-951    |
| LOAD / VOLT METER              | 50-380067      |
| OIL TEMP & PRE INDICATOR       | 124.552-1      |
| PFCS INDICATOR                 | 40-603-3       |
| PFCS INDICATOR                 | H188C          |
| PICTORIAL NAVIGATION INDICATOR | 066-3013-05    |
| PICTORIAL NAVIGATION INDICATOR | 066-3027-19    |
| PICTORIAL NAVIGATION INDICATOR | 066-3046-00    |
| PICTORIAL NAVIGATION INDICATOR | 066-3046-01    |
| PICTORIAL NAVIGATION INDICATOR | 066-3046-03    |
| PICTORIAL NAVIGATION INDICATOR | 066-3046-07    |
| PROP RPM INDICATOR             | 10169N02R00    |
| PROP RPM INDICATOR             | 10169N03R00    |
| PROP RPM INDICATOR             | 224-917-012    |
| PROP RPM INDICATOR             | SEL-OC29DA     |
| PROP RPM INDICATOR             | SEL-OC29DF     |
| PSI INDICATOR                  | 05167-18340906 |
| RADIO ALTIMETER INDICATOR      | 1782993-655    |
| RADIO ALTIMETER INDICATOR      | 2105D-B-6      |
| RADIO ALTIMETER INDICATOR      | 2107LB-6-3     |
| RADIO ALTIMETER INDICATOR      | 2108D-B-6      |
| RADIO ALTIMETER INDICATOR      | 3137LB63C      |
| RADIO ALTIMETER INDICATOR      | 3137L-B-6-3-C  |
| RADIO ALTIMETER INDICATOR      | 622-0171-001   |
| RADIO ALTIMETER INDICATOR      | 622-2937-004   |
| RADIO ALTIMETER INDICATOR      | 7000839-902    |
| RADIO ALTIMETER INDICATOR      | ID-998/ASN     |
| RADIO MAGNETIC INDICATOR       | 066-3038-00    |
| RADIO MAGNETIC INDICATOR       | 4002963-444    |
| RADIO MAGNETIC INDICATOR       | 4002963-445    |
| RADIO MAGNETIC INDICATOR       | 520-3115-017   |
| RADIO MAGNETIC INDICATOR       | 622-0555-003   |

| Part Description              | Part Number    |
|-------------------------------|----------------|
| RADIO MAGNETIC INDICATOR      | 622-2506-003   |
| RADIO MAGNETIC INDICATOR      | 622-2506-004   |
| RADIO MAGNETIC INDICATOR      | 622-2506-006   |
| STANDBY ALTIMETER INDICATOR   | 8047/20DHB     |
| STANDBY ALTIMETER INDICATOR   | WL1604AM2      |
| TACHOMETER                    | 8DJ120AAP1     |
| TACHOMETER                    | 8DJ148CAC1     |
| TACHOMETER                    | 8DJ81LAA2      |
| TACHOMETER                    | D1-112-5025    |
| TEMP INDICATOR                | 163B103A       |
| TEMP, THERMOCOUPLE            | 152B206        |
| TORQUE INDICATOR              | 10167N02W00    |
| TORQUE INDICATOR              | 3571214-6004   |
| TORQUE INDICATOR              | SEDL-0C2P      |
| TORQUE INDICATOR              | SEL-0C2N       |
| TRACK FLAP POSITION INDICATOR | 4428-150-80-10 |
| TURN AND SLIP INDICATOR       | 1234T100-7TZ   |
| TURN AND SLIP INDICATOR       | 2800(7315)     |
| TURN AND SLIP INDICATOR       | 4099B          |
| TURN AND SLIP INDICATOR       | A1050-4        |
| TURN AND SLIP INDICATOR       | A1620-03       |
| TURN AND SLIP INDICATOR       | A5930-02       |
| TURN AND SLIP INDICATOR       | M3520-6        |
| TURN AND SLIP INDICATOR       | R.C.A.2        |
| TURN COORDINATOR              | 5400-7425-4    |
| TURN COORDINATOR              | 601-009-950    |
| VERTICAL GYRO                 | 7000622-901    |
| VERTICAL SPEED INDICATOR      | 30230-1174     |
| VERTICAL SPEED INDICATOR      | 30260-1117     |
| VERTICAL SPEED INDICATOR      | 7000-C92N2     |
| VERTICAL SPEED INDICATOR      | 7040-B4        |
| VERTICAL SPEED INDICATOR      | SLZ9145        |